

**Experiment 11:**                      **Write a Program to read PH value from various substances like Lime, water and Milk using PH sensor with Arduino Board**

**Date : 16.10.2025**

**Aim:**

To write a program to read PH value from various substances using a PH sensor with Arduino Board.

**Components Required:**

S.No	Components Name	Range/Rating	Quantity
1	Universal Bread Board		1
2	Arduino Uno board		1
3	Ph sensor		1
4	Potentiometer (to simulate pH sensor output)		1
5	LCD Display Board		1
6	USB Cable		1
7	Jumper Wires		required


**Hardware Setup:**

**Connect LCD Display with Digital Pins**


**Connect PH Senor pin with A0 and other pin with +5vcc and GND**

**Arrange the wires as in the following diagram**

PH sensor 4502C



## Connection Diagram: -



## Program

```
const int potPin=A0;
float ph;
float Value=0;

void setup() {
  // put your setup code here, to run once:
  Serial.begin(115200); // or Serial.begin(9600)
  pinMode(potPin,INPUT);
  delay(1000);
}

void loop(){
```

```
Value= analogRead(potPin);  
Serial.print(Value);  
Serial.print(" | ");  
float voltage=Value*(3.3/4095.0);  
ph=(3.3*voltage);  
Serial.println(ph);  
delay(500);  
}
```

### **Simulate in Tinkercad**

#### 1. Components Needed:

- Arduino Uno
- Potentiometer (to simulate pH sensor output)
- Wires and Breadboard


#### 2. Setup:

- Connect the middle pin of the potentiometer to A0 on the Arduino.
- Connect one side pin of the potentiometer to 5V and the other to GND.
- Upload the code to the Arduino in Tinkercad.

#### 3. Simulation:

- Adjust the potentiometer to simulate different pH levels.
- Open the Serial Monitor to view the analog value, voltage, and simulated pH value.

## OutPut



## Working Observation:

- The Lime PH value is 2.8.
- The Milk Value is between 6.5 to 6.7
- Water PH Value is 7

**RESULT:** The PH value for the various substance is obtained by employing the PH sensor with Arduino microcontroller Board and Tested successfully.